


DESPIECE GOES 625UTS



[illegible]

[illegible][illegible]

[illegible][illegible]

[illegible][illegible]

N°	REFERENCIA	DESCRIPCION	UDS
1	0180-014009-0010	HOLDER SCREW, OIL SEAL	3
2	0180-014007-0010	HOLDER,OIL SEAL	1
3	0180-014008	OIL SEAL 28×52×7	1
4	30400-02800	BEARING60/28	1
5	0010-080012-0030	BOLT M6×32	3
6	0010-013010-0030	BOLT M6×50	1
7	0010-013009-0030	BOLT M6×40	8
8	0010-021009	SEAL RING, PLUG	1
9	0010-021008-0030	PLUG, INSPECTION	1
10	0180-014001-0080	COVER, LEFT CRANKCASE	1
11	0180-014003-0010	LEAD HOLDER	1
12	0180-014004-0020	BOLT, LEAD HOLDER	2
13	0180-014002	GASKET, LEFT CRANKCASE COVER	1
14	0180-014010	CLAMP	4

[illegible]

[illegible][illegible]

[illegible][illegible]

E08 CYLINDER HEAD

Nº	REFERENCIA	DESCRIPCION	UDS
1	0010-011700-0010	THRUST NUT M8	1
2	0180-022009-0010	STUD M8×68	1
3	0600-022200	GASKET,CYLINDER HEAD	1
4	30204-060810	NUT	2
5	0180-022001-0020	STUD M6×70	2
6	0010-080013-0030	BOLT M6×22	2
7	01A0-022200	WATER OUTLET JOINT, CYLINDER HEAD	1
8	018B-022810	WATER TEMPERATURE SENSOR	1
9	0180-022810	THERMOSTAT	1
10	01A0-022102	PIPE JOINT	1
11	0110-022400	SPARK PLUG	1
12	0180-022010-0010	SCREW M6	2
13	01A0-110005	CLIP	1
14	018B-022900	INJECTOR SEAT	1
15	0180-022011	O-RING 40×2.4	1
16	0600-022004	VALVE, INTAKE	2
17	0180-022008-0050	LOWER SEAT, VALVE SPRING	4
18	0010-022500	SEAL RING SET, VALVE STEM	4
19	0180-022006-0050	VALVE SPRING	4
20	0180-022007-0050	UPPER SEAT, VALVE SPRING	4
21	0010-022006-0030	LOCK CLIP, VALVE	8
22	0180-022012-0010	CYLINDER BOLT(L)	2
23	0180-022013-0010	CYLINDER BOLT(R)	2
24	0180-022014	WASHER, CYLINDER BOLT	4
25	0010-080008	DOWEL PIN φ8×14	2
26	0010-060012-0030	BOLT M6×30	2
27	0600-022005	VALVE, EXHAUST	2
28	0180-022003-0010	STUD M8×42	2
29	0180-022300	GASKET, EXHAUST PIPE	1
31	0180-022015	BREATHER HOSE	1
32	30601-207050	CLAMP A6.5	2




[illegible][illegible]

[illegible][illegible]

[illegible][illegible]

[illegible][illegible]


E13 CLUTCH & CVT

[illegible]

[illegible][illegible]

[illegible][illegible]

E16 CLUTCH HOUSING

[illegible]


[illegible][illegible]

E18 TRANSMISSION I

[illegible]

[illegible][illegible]

[illegible][illegible]

[illegible][illegible]

[illegible][illegible]

[illegible][illegible]


[illegible][illegible]

[illegible][illegible]

[illegible][illegible]

[illegible][illegible]

F03 FRONT FACE


[illegible]

[illegible][illegible]


[illegible][illegible]

[illegible][illegible]

F07 PLASTICS IV

[illegible]

F08 PLASTICS V


[illegible]

F09 FRAME ASSY

Nº	REFERENCIA	DESCRIPCION	UDS
1	9060-030100	FRAME ASSY	1
2	30006-080016840	BOLT	22
3	9060-040024	SOLEPLATE	1
4	9060-040028	SOLEPLATE GASKET	16
5	30006-060016840	BOLT	35
6	30303-060142	SPRING GASKET	16
7	9060-037300	LOWER BRACKET,RADIATOR	1
8	30902-0400820	RIVET	2
9-1	9010-190015	NAME PLATE DOT	1
9-2	9060-190010	NAME PLATE EEC	1
10	9060-037250	MOUNTING BRACKET, FRONT TOP COVER	1
11	30006-060012840	BOLT	15
12	9060-037110	UPPER BRACKET, RESERVOIR TANK	1
13	9060-038010	RELAY SEAT	1
14	30204-080840	NUT	2
15	30006-080040840	BOLT	4
16	9060-037663	LIMIT ROD , SEAT	2
17	9060-038030	SEAT SUPPORT(RH)	1
18	9060-037570	PARKING BRAKE BRACKET	1
19	9060-038310	REINFORCEMENT BRACKET, PARKING BRAKE	1
20	9060-038020	SEAT SUPPORT(LH)	1
21	90606-030491	MULCH OIL BOX (THIRD)	1
22	90606-030488	MULCH OIL BOX (SECOND)	1
23	30006-080048840	BOLT	4
24	9060-037710	X-GIRDER ASSEMBLY	1
25	9060-038203	PALETTE, IDLE VALVE	1
26	9060-031670	HEAT INSULATION PLATE , REAR AXLE	1
27	9060-038130	FRONT CONNECTION BRACKET , REAR AXLE	1
28	9060-037740	FRONT SUPPORT BEAM COMP.	1
29	30006-080035840	BOLT	4
30	30006-080040840	BOLT	2
31	9060-037850	SUPPORT BEAM(2), CARGO BOX	1
32	9060-037810	SUPPORT BEAM(1), CARGO BOX	1
33	9060-038202	JOINT PLATE(RH),BUMPER	1
34	9060-038201	JOINT PLATE(LH),BUMPER	1
35	30006-102020840	BOLT	8
36	9060-038120	HEAT INSULATION PLATE ASSEMBLY	1
37	9060-038123	CIRCULAR PIUG	2

[illegible][illegible]


F11 REAR SUSPENSION



Nº	REFERENCIA	DESCRIPCION	UDS
1	30006-060012840	BOLT	10
2	9060-060001	GUARD, REAR BRAKE DISC	2
3	30800-06300	ELASTIC RETAINER	2
4	30499-03081	BEARING, HUB	2
5	30204-102840	LOCK NUT	14
6	9010-060900	DUST CAP	8
7	9010-060004	BUSHING	8
8	9060-060702	MIDDLE SHAFT(LOWER), REAR WHEEL SHAFT SUPPOR	2
9	9060-060704	MOUNTING SHAFT, REAR WHEEL SHAFT SUPPORT	2
10	9060-060803	SUPPORT, REAR WHEEL SHAFT(RH)	1
11	3120100	OIL CUP	10
12	9060-060701	MIDDLE SHAFT(UPPER), REAR WHEEL SHAFT SUPPOR	2
13	30006-102090840	BOLT	2
14	30006-102055840	BOLT	4
15	9060-060500	REAR SHOCK ABSORBER	2
16	9060-050003	SHORT BUSHING , SUSPENSION ARM	8
17	9060-050201	REAR CV SHIELD	2
18	30006-080016840	BOLT	4
19	9060-060410	REAR LOWER ARM (RH)	1
20	9060-060201	SPACER, REAR LOWER ARM	4
21	9060-060102	MOUNTING SHAFT, REAR ARM	2
22	9060-050102	BUSHING, FRONT ARM	4
23	9060-060101	SPACER, REAR UPPER ARM	2
24	9060-060310	REAR UPPER ARM (RH)	1
25	9060-060110	REAR UPPER ARM (LH)	1
26	9060-060210	REAR ARM (LH & LOWER)	1
27	9060-060703	SUPPORT, REAR WHEEL SHAFT(LH)	1
28	9060-060622	RUBBER SEAT, LINKAGE BAR	8
29	9060-060623	WASHER, LINKAGE BAR	8
30	9060-060621	LINKAGE BAR	2
31	30204-080840	NUT	4
32	9060-060602	RUBBER SEAT, STABILIZER BAR	2
33	9030-060002	BUSHING, STABILIZER BAR	2
34	9060-060610	REAR STABILIZER BAR	1

[illegible][illegible]


F13 REAR WHEEL

[illegible]

F14 BRAKE SYSTEM

Nº	REFERENCIA	DESCRIPCION	UDS
1	9060-080810	RIGHT BRAKE PAD , FRONT BRAKE	1
2	9060-081010	REAR BRAKE PAD	2
3	9060-080800	RIGHT CALIPER, FRONT BRAKE	1
4	30006-080025840	BOLT	8
5	5190-080104	SEAL WASHER	19
6	9060-080400	RIGHT FLUID HOSE (LOWER), FRONT BRAKE	1
7	9030-080103	BOLT, FLUID BYPASS	4
8	9060-080300	LEFT FLUID HOSE(LOWER), FRONT BRAKE	1
9	9010-080101-B000	BOLT, FLUID BYPASS	1
10	5190-080103	BOLT, FLUID BYPASS	4
11	9060-080900	LEFT CALIPER, FRONT BRAKE	1
12	9060-080101	FLUID HOSE, BRAKE FLUID RESERVOIR	2
13	9060-080500	FRONT FLUID HOSE, REAR BRAKE	1
14	9060-080200	MASTER CYLINDER	1
15	9060-080004	SPRING, BRAKE SWITCH	1
16	9060-081200	FIXING BRACKET, BRAKE PEDAL	1
17	9030-080110	BRAKE FLUID RESERVOIR	2
18	30006-060010840	BOLT	4
19	30006-060020840	BOLT	5
20	9060-105002	BUSHING	2
21	9060-081300	BRAKE PEDAL	1
22	9060-080003	RETURN SPRING	1
23	9030-080102	T-JOINT	1
24	30006-060030840	BOLT	1
25	9060-080700	RIGHT FLUID HOSE (LOWER), REAR BRAKE	1
26	9060-080600	LEFT FLUID HOSE (LOWER), REAR BRAKE	1
27	30102-102035840	SCREW	4
28	9060-081000	REAR CALIPER (RH)	1
29	9060-081100	REAR CALIPER (LH)	1
30	9060-080100	HYDRAULIC BRAKE	1
31	30306-120142	PLAIN WASHER	1
32	30903-0322220	COTTER PIN	1
33	9010-080104	CIRCLIP	7
34	9010-080405	CIRCLIP	4
35	9060-080910	LEFT BRAKE PAD , FRONT BRAKE	1

F15 STEERING WHEEL



Nº	REFERENCIA	DESCRIPCION	UDS
1	9060-190001	CFMOTO LOGO	1
2	9060-100003	CAP, STEERING WHEEL	1
3	30306-120142	PLAIN WASHER	1
4	9060-103000	STEERING WHEEL	1
6	9060-102002	UPPER BOLT,GAS SPRING	1
7	9060-102000	GAS SRPING	1
8	9060-102003	LOWER BOLT, GAS SPRING	1
9	30006-080025840	BOLT	4
10	9060-100009	NYLON BUSHING	2
11	9060-100008	METAL BUSHING	2
12	9060-101009	BRACKET, GAS SPRING	1
13	30202-060140	NUT	2
14	30006-080020840	BOLT	6
15	9060-100001-1000	STEERING COLUMN	1
16	9060-010210	LOCK,STEERING WHEEL	1
17	9060-101008	MOUNING BRACKET, STEERING WHEEL	1
18	30107-060012440	SCREW	2
19	30204-122840	NUT	1
20	9060-104010-1000	UNIVERSAL JOINT	1
21	9060-104060	STEERING MOTOR	1
22	30019-080075840	BOLT	1
23	9060-104020	TIE ROD ASSY	2
24	30207-102840	NUT	2
25	30903-0322220	COTTER PIN	2
26	9030-101122	CLIP	2
27	9060-104002	JACKET OF JOINT-L	1
28	9030-000107	A-CLIP (50 ~ 70)	1
29	30019-080090840	BOLT	2
30	9060-104001	JACKET OF JOINT-R	1
31	30204-080840	NUT	5
32	30006-080016840	BOLT	4
33	9060-037450	MOUNTING SEAT, STEERING MOTOR	1
34	9060-105020	THROTTLE CABLE	1
35	9060-105004	THROTTLE PEDAL	1
36	30306-080142	WASHR	1
37	30903-0162020	COTTER PIN	1
38	30903-0322220	COTTER PIN	1
39	9060-105002	BUSH(NYLON)	2

[illegible]


[illegible][illegible]

[illegible][illegible]

F18 FUEL TANK

[illegible]

F19 CVT COOLING SYSTEM

[illegible]

[illegible]


F23 FRONT & REAR BUMPER			
Nº	REFERENCIA	DESCRIPCION	UDS
1.1	9060-230100	FRONT BUMPER	1
1.2	9060-230100-1000	FRONT BUMPER	1
2	9060-230200	REAR BUMPER	1
2.1	9060-230200	REAR BUMPER	1
2.2	9060-230200-1000	REAR BUMPER	1
4	30102-102020840	SCREW	4
5	9060-037470	HAND HOLD, PASSENGER	1
6	30006-080045840	BOLT	1
7	9060-037530	FIXING BRACKET, RH	1
8	30006-080045840	BOLT	1
9	9060-037510	FIXING BRACKET, LH	1

[illegible][illegible]

[illegible] $\frac{1}{2}$

F26 ELECTRIC SYSTEM


Nº	REFERENCIA	DESCRIPCION	UDS
1	901B-150700	POWER SOCKET	1
2	901B-150702	DUSTPROOF CAP	1
3	30006-060025840	BOLT	2
4	018B-178000	IGNITION COIL	1
5	01AA-178200	HIGH-TENSION CABLE	1
6	9060-010110	LOCK ASSY	1
7	9010-150002	RUBBER, AUXILIARY RELAY	6
8	9010-150350	AUXILIARY RELAY	6
9	9060-000001	BREATHER HOSE □, IDLE SPEED	1
10	30601-112020	CLAMP	5
11	018B-172000	CANISTER, ABV	1
12	901F-000005	RUBBER, ABV	1
13	30601-116020	CLAMP	1
14	9060-000400	BREATHER HOSE □, IDLE SPEED	1
15	9060-150100	MAIN CABLE	1
16	9010-150004	MOUNTING TIES	15
17	9010-150005	CIRCLIP	10
18	30006-060012840	BOLT	3
19	8030-151400	DIVERTER RELAY	3
20	806A-151301	FUSE (7.5A)	1
21	806A-151302	FUSE (10A)	2
22	806A-151303	FUSE (15A)	3
23	806A-151304	FUSE CASE	1
24	806A-151300	FUSE BOX	1
25	31021800	BATTERY	1
26	01AA-177000	REGULATOR	1
27	30006-060030840	BOLT	2
28	9060-030489	ALUM. PLATE, REGULATOR	1
29	5020-150700	ELECTRIC HORN 12V	1
30	30006-080014840	BOLT	1
31	6060-150800	CLOCK ADJUST BUTTON	1
32	8010-151000	FLASHER	1
33	8010-150002	CUSHION, FLASHER	1
34	30202-060840	NUT	2
35	9060-000500	BREATHER HOSE □, IDLE SPEED	1
36	018B-175000	INTAKE AIR PRESSURE SENSOR	1
37	30105-050016440	SCREW	4
38	060B-174000	ECU	1



[illegible][illegible]

[illegible][illegible]

F29 FRONT AXLE




Nº	REFERENCIA	DESCRIPCION	UDS
1	Q810-310000	FRONT AXLE	1
2	0180-312005-0050	NUT WASHER	1
3	0180-312006	O-RING 14×6.8	1
4	0181-312007-0050	COUPLER	1
5	0180-312002	OIL SEAL 48×65×9	1
6	Q810-311003	RETAINER, BEARING	1
7	30400-02502	BEARING 6305	1
8-1	0180-310006	ADJUST SHIM 61×53×0.1	1
8-2	0180-310006-0001	ADJUST SHIM 61×53×0.2	1
8-3	0180-310006-0002	ADJUST SHIM 61×53×0.3	1
8-4	0180-310006-0003	ADJUST SHIM 61×53×0.4	1
8-5	0180-310006-0004	ADJUST SHIM 61×53×0.5	1
8-6	0180-310006-0005	ADJUST SHIM 61×53×1.0	1
9	Q810-310010	BEVEL GEAR COMP. FRONT AXLE	1
10	30499-01502	NEEDLE BEARING	1
11	Q810-311001	FRONT AXLE CASE	1
12	0180-021008-0030	BOLT M14×1.25×12	2
13	0180-011006	WASHER 14	2
14	0180-311004-0020	JOINT, BREATHER PIPE	1
15	0180-311001	OIL SEAL 24×38×8	2
16	30130-080010820	SCREW M8×10	1
17	0180-310002	PIN SHAFT	1
18	30102-080020820	HEX SCREW M8×20	4
19	0181-314000	GEAR MOTOR, FRONT AXLE	1
20	0180-310001	O-RING 81.2×1.9	1
21	0180-315000	SHIFT FORK	1
22	30400-03501	BEARING 16007	1
23	30800-06200	RETAINER 62	1
24	0180-311003-0050	DRIVE CLUTCH COVER	1
25	0180-310003-0050	SPLINE BUSH	1
26-1	0180-310004	ADJUST SHIM83×71×0.1	1
26-2	0180-310004-0001	ADJUST SHIM83×71×0.2	1
26-3	0180-310004-0002	ADJUST SHIM 83×71×0.3	1
26-4	0180-310004-0003	ADJUST SHIM 83×71×0.4	1
26-5	0180-310004-0004	ADJUST SHIM 83×71×0.5	1
26-6	0180-310004-0005	ADJUST SHIM83×71×1.0	1
27	30499-06000	BEARING 61912	1
28	0180-313007-0050	FORK PIN	1

[illegible][illegible]

F30 REAR AXLE

Nº	REFERENCIA	DESCRIPCION	UDS
1	Q510-330000	REAR AXLE ASSY	1
2	30008-080025810	BOLT M8X25	6
3	0180-330004-0030	BOLT M10X1.25x25	2
4	0180-334006-0030	NUT M8	1
5	0180-334004	NUT M8	1
6	0180-334005-0030	SCREW M8x45	1
7	0180-334001-0080	RIGHT CASE COVER, REAR AXLE	1
8	0180-334002	O-RING 151x3	1
9	30499-08500	BEARING 16017/C2	1
10-1	0180-330002	ADJUST SHIM (2) 100x86x0.2	1
10-2	0180-330002-0001	ADJUST SHIM (2) 100x86x0.3	1
10-3	0180-330002-0002	ADJUST SHIM (2) 100x86x0.4	1
11	Q510-330010	BEVEL GEAR COMP, REAR AXLE	1
12-1	0180-330001	ADJUST SHIM (1) 66.8x55.2x1.0	1
12-2	0180-330001-0001	ADJUST SHIM (1) 66.8x55.2x1.2	1
12-3	0180-330001-0002	ADJUST SHIM (1) 66.8x55.2x1.4	1
12-4	0180-330001-0003	ADJUST SHIM (1) 66.8x55.2x1.6	1
12-5	0180-330001-0004	ADJUST SHIM (1) 66.8x55.2x1.8	1
13	30404-05500	NEEDLE BEARING	1
14	Q510-332001	CASE, REAR AXLE	1
15	0180-011006	WASHER 14	2
16	0180-021008-0030	BOLT M14x1.25x12	2
17	0180-332006	JOINT, BREATHER PIPE	1
18	30403-01700	NEEDLE BEARING	1
19-1	0180-330003	ADJUST SHIM 0.5	1
19-2	0180-330003-0001	ADJUST SHIM 0.6	1
19-3	0180-330003-0002	ADJUST SHIM 0.4	1
20	0180-334003	OIL SEAL SD4 65x90x9 NS	1
21	Q510-331003	BEARING RETAINER	1
22	30400-02502	BEARING 6305	1
23	0180-331004	O-RING 64.5x3	1
24	Q510-331001	BEARING SEAT, REAR AXLE	1
25	30008-080035810	BOLT M8X35	4
26	0180-331007	OIL SEAL	1
27	9060-300104	FLANGE, REAR AXLE	1
28	0180-331008-0050	WASHER 12.5X30X4	1
29	0180-331009-0020	NUT M12X1.25	1


F31 AIR FILTER ASSY

[illegible]

[illegible][illegible]

[illegible][illegible]

F34 NETS

[illegible]

[illegible][illegible]