

MAINTENANCE

Shock preload adjustment

The front and rear shock spring preload and damping can be adjusted to for rider weight, cargo, and riding conditions. Always adjust the shock absorbers on the left and right side to the same setting, and reset them to the initial setting after carrying loads.

Adjust the spring preload:

A = Soft ~ B = Hard

- To increase the spring preload, loosen the lock nut [2] and turn the adjusting ring [1] in direction 'B'.
- To decrease the spring preload, loosen the lock nut [2] and turn the adjusting ring [1] in direction 'A'.

NOTE:

A special collar wrench is included in the tool kit to make spring preload adjustments.

